

①  [socomec](http://socomec.com) www
Technical support/Product software



②  *Net Vision 8*

 <https://socomec.co.uk/en-gb/net-vision-8-ups-websnmp-ethernet-card-iot-gateway>

③  NetVision Explorer  + 

④ NetVision Explorer.exe



	Name	Location	IP	Action	F/W Ver.	Model	MAC
☐			192.168.1.10	   	8.00	Nv8 card	00-00-00 ff c4 3a

⑥ Click  → Browse → http://IP ⑦ Login


admin
MAC : xx xx xx **FFC43A**

⑧ Please Change Password
Enter New PASSWORD
Password

12 Char min **A-Z a-z 0-9 !#%&**

NET VISION

quick start guide for Windows®



⑤

Login

Username

Password

Connect